


PERMATIMBER® FENCING | GATE INSTALLATION

BEFORE YOU START

With correct installation, Perma Fence™ by PermaTimber® will provide years of security and enjoyment. These installation instructions should be read in conjunction with the PermaTimber® Fence Design Guide. Please ensure your fence and gate plans are compliant with fencing local law and government requirements.

COMPONENTS AND TOOLS REQUIRED



COMPONENTS	TOOLS
<input type="checkbox"/> PermaTimber® Fence Panels	<input type="checkbox"/> Drill
<input type="checkbox"/> PermaTimber® Fence Single Post	<input type="checkbox"/> Pan Head Screw or Rivets
<input type="checkbox"/> PermaTimber® Fence Single Post Cap	<input type="checkbox"/> Shovel / Post Digger
<input type="checkbox"/> PermaTimber® Fence Top / Bottom Rail	<input type="checkbox"/> Concrete
<input type="checkbox"/> 50 x 6 Aluminium Flat Bar (if required)	<input type="checkbox"/> Tape Measure
<input type="checkbox"/> 50 x 50 Aluminium / Steel SHS Post (if required)	<input type="checkbox"/> Spirit Level
<input type="checkbox"/> 50 x 50 Aluminium / Steel SHS Post Cap (if required)	<input type="checkbox"/> Cutting Saw
<input type="checkbox"/> Gate Hinge (ensure suitable for gate weight)	
<input type="checkbox"/> Gate Latch of choice	


PERMATIMBER® FENCING | GATE INSTALLATION

INSTALL THE POSTS

Determine the size and location where you would like the gate to be installed.

Mark out the position of the posts and dig the footings as per the recommendations in the PermaTimber® Fence Design Guide.

Place the post caps on top of all posts to prevent water from entering. Position the posts in the footings and cement into place. Allow the concrete to cure for at least 48 hours before moving onto the next step.




ASSEMBLE THE GATE

Cut / rip the PermaTimber® Fence Panels to the desired size, ensuring both ends are flat. Slot the PermaTimber® Fence Panels together to create the main section of the gate.

Fix the 50 x 6mm Aluminium Flat Bar to the hinge side of the gate with screws.

Use the PermaTimber® Fence Top/Bottom Rail to frame the PermaTimber® Fence panels, using screws or rivets to fix.




GATE LATCH AND HINGES



Fix the gate hinges to the gate and align with the post. Three hinges are required; please ensure you have selected the appropriate type of hinge for the weight / size of the gate.

Check that the top of the gate is flush with the top of the posts and screw the hinges.

Finish off the gate by installing a latch of your choosing



PERMATIMBER® FENCING | GATE CONFIGURATIONS



PERMATIMBER® FENCING | GATE CONFIGURATIONS

